



# Protect Your Vehicle Well Beyond the Manufacturer's Warranty



## Repairs Are Expensive!

Average Repair Costs ■ Domestic/Asian Vehicles ■ European Vehicles

Air Conditioning System

\$1,648 / \$2,149

Transmission

\$5,482 / \$8,875

Starter

\$473 / \$841

Alternator

\$722 / \$1,571

Engine

\$10,655 / \$15,964

Rack & Pinion

\$1,927 / \$2,871

Fuel Pump

\$747 / \$948

Control Arm


\$656 / \$787

Brake Caliper


\$570 / \$662

Power Window Motor

\$605 / \$776



## Breakdown Risk and Cost Increase with Time and Miles!



## Coverage Benefits During the Manufacturer's Warranty and Beyond!

**24-Hour Roadside Assistance** up to \$100 for towing, lost key, lock-out and other road services like jump start and fluid delivery

**Rental Vehicle Assistance** up to \$35 per day (maximum 5 days) while your vehicle is in the shop for covered repairs. Maximum 10 days if parts are delayed

**Key Fob Replacement** up to \$400 per year (Ultimate and Deluxe Protection Only)

**Tire Protection** up to \$150 per tire for repair or replacement due to damage during their normal life by glass, nails or other road hazards. Maximum of \$600

**Trip Interruption** up to \$150 per day for meals and lodging up to three days (\$450 per occurrence) if you are stranded more than 100 miles away from your home

**Total Loss Refund.** If your vehicle is deemed a total loss due to physical damage or theft we will refund the agreement purchase price (Not available in all states)



**Ultimate Protection.** Factory-like coverage that remedies ANY mechanical or electrical breakdown of your vehicle that is not specifically excluded. See Exclusions Overview below for details.

Named Component Plan Options\* ☒ Deluxe Protection

ENGINE		
Cylinder block and internal components	<div></div>	<div></div>
Cylinder head(s)	<div></div>	<div></div>
Engine oil pressure gauge	<div></div>	<div></div>
Flexplate	<div></div>	<div></div>
Flywheel	<div></div>	<div></div>
Harmonic balancer	<div></div>	<div></div>
Intake manifold	<div></div>	<div></div>
Mounts	<div></div>	<div></div>
Oil pan	<div></div>	<div></div>
Oil pump	<div></div>	<div></div>
Timing belt	<div></div>	<div></div>
Timing chain	<div></div>	<div></div>
Timing chain guides	<div></div>	<div></div>
Timing chain sprockets	<div></div>	<div></div>
Timing chain tensioners	<div></div>	<div></div>
Timing cover	<div></div>	<div></div>
Timing gears	<div></div>	<div></div>
Turbocharger/Supercharger	<div></div>	<div></div>
Valve cover(s)	<div></div>	<div></div>
Wastegate	<div></div>	<div></div>

TRANSMISSION / TRANSAXLE		
Gear shift lever	<div></div>	<div></div>
Mounts	<div></div>	<div></div>
Pan	<div></div>	<div></div>
Torque converter	<div></div>	<div></div>
Transmission and transaxle cases and internal components	<div></div>	<div></div>
Transmission oil cooler	<div></div>	<div></div>
Transmission shift linkage	<div></div>	<div></div>
Vacuum modulator	<div></div>	<div></div>

DRIVE AXLE		
Axle shaft bearings	<div></div>	<div></div>
Axle shafts	<div></div>	<div></div>
Axles	<div></div>	<div></div>
Center bearings	<div></div>	<div></div>
Constant velocity joints	<div></div>	<div></div>
Final drive and axle housings and internal components	<div></div>	<div></div>
Hub bearings	<div></div>	<div></div>
Hubs	<div></div>	<div></div>
Locking rings	<div></div>	<div></div>
Propeller shafts	<div></div>	<div></div>
Universal joints	<div></div>	<div></div>
Yokes	<div></div>	<div></div>

TRANSFER CASE		
Mounts	<div></div>	<div></div>
Transfer case and internal components	<div></div>	<div></div>

HYBRID / ELECTRIC		
Battery cooling blower assembly	<div></div>	<div></div>
Battery cooling blower motor control	<div></div>	<div></div>
Battery heater	<div></div>	<div></div>
Battery junction board	<div></div>	<div></div>
Battery junction bus	<div></div>	<div></div>
Battery thermistor	<div></div>	<div></div>

☐ Select Protection - Limited to \$3,500

HYBRID / ELECTRIC		
Combination meter assembly	<div></div>	<div></div>
Combination meter computer	<div></div>	<div></div>
Control panel display unit	<div></div>	<div></div>
Current sensor	<div></div>	<div></div>
Electric drive motor assembly	<div></div>	<div></div>
Electric drive motor mounts	<div></div>	<div></div>
Electric drive motor power relay	<div></div>	<div></div>
Electric inverter assembly and converter	<div></div>	<div></div>
Electric water pump; cooling system reservoir	<div></div>	<div></div>
Hybrid starter assembly	<div></div>	<div></div>
Main switch assembly	<div></div>	<div></div>
Onboard battery charger	<div></div>	<div></div>
Onboard power generator assembly	<div></div>	<div></div>
Power source control computer	<div></div>	<div></div>
System main relay	<div></div>	<div></div>

STEERING		
Control valve and cylinder	<div></div>	<div></div>
Drag link	<div></div>	<div></div>
Gear housing, rack assembly and their Internal components	<div></div>	<div></div>
Idler arm	<div></div>	<div></div>
Pitman arm	<div></div>	<div></div>
Power cylinder assembly	<div></div>	<div></div>
Power steering pump	<div></div>	<div></div>
Power steering pump mounting bracket	<div></div>	<div></div>
Power steering pump pulley	<div></div>	<div></div>
Steering column shaft bearings	<div></div>	<div></div>
Steering column shaft couplings	<div></div>	<div></div>
Steering column shaft(s)	<div></div>	<div></div>
Steering knuckle	<div></div>	<div></div>

BRAKE		
Backing plate assembly	<div></div>	<div></div>
Brake lines and fittings	<div></div>	<div></div>
Brake pedal assembly	<div></div>	<div></div>
Master cylinder	<div></div>	<div></div>
Parking brake cable	<div></div>	<div></div>
Parking brake pedal	<div></div>	<div></div>
Parking brake release mechanism	<div></div>	<div></div>
Power brake assist boosters	<div></div>	<div></div>
Self adjusters	<div></div>	<div></div>

SUSPENSION		
Control arm bushings	<div></div>	<div></div>
Control arm shafts	<div></div>	<div></div>
Spindle and support	<div></div>	<div></div>
Strut bar	<div></div>	<div></div>
Sway bar bushing	<div></div>	<div></div>
Sway bar linkage	<div></div>	<div></div>
Upper and lower ball joints	<div></div>	<div></div>
Upper and lower control arms	<div></div>	<div></div>
Wheel bearings	<div></div>	<div></div>

ELECTRICAL		
Auxiliary power point	<div></div>	<div></div>
Backup light switch	<div></div>	<div></div>

ELECTRICAL		
Brake light switch	<div></div>	<div></div>
Cigarette lighter(s)	<div></div>	<div></div>
Clock	<div></div>	<div></div>
Cruise control actuator	<div></div>	<div></div>
Cruise control module	<div></div>	<div></div>
Door operated courtesy light switches	<div></div>	<div></div>
Electric door lock relay and actuator	<div></div>	<div></div>
Electric hatchback actuators	<div></div>	<div></div>
Electric mirror motors	<div></div>	<div></div>
Electric tailgate actuators	<div></div>	<div></div>
Electric trunk actuators	<div></div>	<div></div>
Electric window motors	<div></div>	<div></div>
Headlamp dimmer switch	<div></div>	<div></div>
Horn	<div></div>	<div></div>
Horn relay	<div></div>	<div></div>
Manually operated electrical switches	<div></div>	<div></div>
Map lights	<div></div>	<div></div>
Neutral safety switch	<div></div>	<div></div>
Starter motor	<div></div>	<div></div>
Starter motor drive	<div></div>	<div></div>
Starter motor solenoid	<div></div>	<div></div>
Tachometer	<div></div>	<div></div>
Windshield washer pump	<div></div>	<div></div>
Wiper motors	<div></div>	<div></div>

SPECIAL ELECTRONICS		
Back up camera	<div></div>	<div></div>
DVD player	<div></div>	<div></div>
GPS/Navigation system	<div></div>	<div></div>
Night vision system	<div></div>	<div></div>
Proximity sensors	<div></div>	<div></div>
Video game player	<div></div>	<div></div>
Video touch screen	<div></div>	<div></div>

FUEL SYSTEM		
Accelerator pedal	<div></div>	<div></div>
Accelerator pedal linkage	<div></div>	<div></div>
Fuel gauge	<div></div>	<div></div>
Fuel level sending unit	<div></div>	<div></div>
Fuel pressure regulator	<div></div>	<div></div>
Fuel pressure sensor	<div></div>	<div></div>
Fuel pump	<div></div>	<div></div>
Fuel pump relay	<div></div>	<div></div>
Fuel shutoff control	<div></div>	<div></div>
Fuel tank	<div></div>	<div></div>
Fuel tank filler pipe	<div></div>	<div></div>
Metal fuel lines fuel pump relay	<div></div>	<div></div>

AIR CONDITIONING		
Accumulator/Drier	<div></div>	<div></div>
Blower motor	<div></div>	<div></div>
Compressor	<div></div>	<div></div>
Compressor clutch	<div></div>	<div></div>
Compressor clutch coil	<div></div>	<div></div>
Compressor mounting bracket	<div></div>	<div></div>
Compressor pulley	<div></div>	<div></div>

(Parts not listed are not covered)

AIR CONDITIONING		
Condenser	<div></div>	<div></div>
Evaporator	<div></div>	<div></div>
Expansion valve	<div></div>	<div></div>
Heater control valve	<div></div>	<div></div>
Idler pulley and bearing	<div></div>	<div></div>
Idler pulley tensioner	<div></div>	<div></div>
Manual temperature control selector head	<div></div>	<div></div>
Orifice tube	<div></div>	<div></div>

IGNITION AND CHARGING		
Alternator	<div></div>	<div></div>
Alternator pulley and mounting bracket	<div></div>	<div></div>
Amp gauge	<div></div>	<div></div>
Camshaft position sensor	<div></div>	<div></div>
Crankshaft position sensor	<div></div>	<div></div>
Electronic ignition distributor	<div></div>	<div></div>
Electronic ignition module	<div></div>	<div></div>
Fuel control temperature sensor	<div></div>	<div></div>
Idle control actuator	<div></div>	<div></div>
Igniter	<div></div>	<div></div>
Ignition coil	<div></div>	<div></div>
Manifold vacuum sensor	<div></div>	<div></div>
Throttle position sensor	<div></div>	<div></div>
Volt gauge	<div></div>	<div></div>
Voltage regulator	<div></div>	<div></div>

ENGINE COOLING		
Electric radiator fan motor relay	<div></div>	<div></div>
Electric radiator fan motor sensor	<div></div>	<div></div>
Electric radiator fan motor switch	<div></div>	<div></div>
Engine coolant temperature gauge	<div></div>	<div></div>
Fan clutch	<div></div>	<div></div>
Fan shroud	<div></div>	<div></div>
Radiator coolant recovery unit	<div></div>	<div></div>
Radiator fan motor	<div></div>	<div></div>
Water pump	<div></div>	<div></div>
Water pump housing	<div></div>	<div></div>
Water pump pulley	<div></div>	<div></div>

SEALS AND GASKETS		
Included for covered parts	<div></div>	<div></div>
In conjunction with a covered repair	<div></div>	<div></div>

CONSEQUENTIAL LOSS – Limited to \$2,000		
Non-covered components damaged by the failure of a covered component	<div></div>	<div></div>

**\*EXCLUSIONS OVERVIEW:** Abuse; misuse; lack of customary maintenance; non-mechanical, electrical, pneumatic, hydraulic components; Normal Maintenance and Service Items. Examples: Batteries, Brake Pads, Shoes/Drums/Rotors, Shocks, Struts, Wiper Blades, etc. Aftermarket equipment. Body Structure and parts, trim, moldings, glass, upholstery, paint, etc. Non-covered parts: Bumpers; Cables; Chassis; Clamps; Fasteners; Convertible Top Assemblies; Exhaust/EGR System; Air Pump and Catalytic Converter; PCV System; Fuel Vapor Recovery System; Hoses; Tubes; Lines and Fittings; Mirrors; Manual Clutch Components; Passenger/Driver Restraint Systems; Seat Components; Suspension Springs and Torsion Bars; Wheels; Tire Pressure Sensors; Fuses; Lights/Bulbs/Lens Assemblies; Audio Speakers; etc. **REFER TO THE AGREEMENT FOR CONDITIONS OF COVERAGE, COMPLETE LIST OF EXCLUSIONS AND YOUR DUTIES.**

## Why Choose Mercury?

- Repairs can be done at any licensed U.S. or Canadian repair facility
- No limit on the number of claims up to maximum liability
- Mercury pays the repairer directly by credit card. Out of pocket expense is limited to your deductible (if any)
- Mercury pays for fluids, filters, taxes and diagnostic fees for covered repairs
- All claims are handled by Mercury, not a third party administrator. Mercury is also the insurer
- Transferable one time for a small fee if you sell to a private party
- Cancellable (prorated based on the greater of time or miles)
- 60 day free look

## Key Considerations

- The risk of unexpected breakdowns increases with vehicle age and miles
- Repairs are expensive and repair costs increase over time
- Unexpected breakdowns can strain your budget and put your good credit at risk
- You effectively lock-in the cost of unexpected breakdowns for the term of the Agreement
- The ability to transfer coverage to a private party may increase your vehicle's resale value along with the chance of its sale

## Repairs Per 100 Vehicles\*

**98**

\*After manufacturer's warranty expiration